

FootCHECK

www.FootCHECKS.com • www.TheDisinfectantSite.com



FootCHECK is a pre-calibrated footbath providing a rapid, simple and convenient way to accurately and consistently achieve the correct concentration for disinfectants used as a part of a biosecurity programme.

- **REMEMBER:** Fill in your audit sticker and/or record sheet.

How to use FootCHECK



- 1** Position footbath on a level floor near a suitable wall. **2** On level ground, prop the bath against a wall to achieve an angle of 45 degrees (as illustrated) and lift the lid. **3** Carefully pour concentrated disinfectant into the appropriate internal measuring chamber, or chambers. Fill the 1% chamber for 1% concentration (half fill for 0.5% concentration). Fill the 2% chamber for 2% concentration or fill both 1% and 2% chambers for 3% concentration. For 4% concentration fill both 1% and 2% chambers (as per 3% concentration) - see point **5** for water level instructions. **4** Lower footbath so that the base is flat on the floor.



- 5** Fill footbath with clean water to final fill line (15 litres) or to level B fill line for 4% concentration (11.25 litres). Swirl bath contents to mix disinfectant. **6** Complete an audit sticker and apply to front of footbath in the space provided. **7** Keep lid closed when not in use to maintain efficacy by keeping contents clean, reducing evaporation or dilution. **8** Dispose of used contents responsibly and in accordance with the disinfectant instructions.

* DEFRA approved rates. **ALWAYS READ THE LABEL AND PRODUCT INFORMATION BEFORE AND AFTER USE.

Remember to use safe technique when lifting any heavy object - weight when full approximately 20kg

VSM Ltd. P.O Box 6447, Kenilworth, Warwickshire, CV8 9EP, United Kingdom • M. +44 (0)7848 742819 • E. info@FootCHECKS.com

For more product information please see our website: www.FootCHECKS.com

www.FootCHECKS.com • www.TheDisinfectantSite.com